


Double Pole Double Throw Momentary Switch (ON)-OFF-(ON)



Note: (1) Switch reqd for each actuator to be controlled.

Switch should be rated at 15 amps or better. One source for these switches would be your local ATV and snowmobile dealer. They stock or can order the switches used to control 12 volt winches used on ATV's. These are excellent as they often are designed to mount on the dash or handlebar, are the correct type (dbl pole dbl throw momentary) and they are more than heavy enough for the load. The instructions for wiring a winch with one of these switches will be the same as an actuator (just substitute actuator for winch).

Power source is 12v DC, either snow machine or separate portable 12 volt power pack. We suggest using a six pole trailer connector between the snow machine and the groomer. Power packs and trailer connectors are available at any auto supply store.